Total Reduced Sulfur

Odor Index

-

DW2

DMDS Me-SH Et-SH



# **ONLINE GAS ANALYZER EXPERTS**

GAS ANALYZER GC 866

# TRS**MEDOR**®

**ppm** (M51) or **ppb** (M52) Online analysis and monitoring of odorous sulfur compounds





Model: M52022 (rack version)

Model: M52022 (wall mounted version)

# **On-line applications:**

Fence line Fermentation process Deodorization process Fugitive emission

## **Targeted compounds:**

Standard version: H2S / SO2 / MM / EM / DMS / DMDS / DES Upon request: IPM / TBM / NPM / MES / 2BM / IBM / NBM / THT

## Main markets:

WWTP / Refineries / Petrochemicals / Gas process sites Ambiant / Industrial air monitoring Odor impact management TRS measurement

Standards:

ISO 19739:2004, DIN 51855/7 ASTM D 7493-08

**Certifications:** 

GOST, ATEX, IECEx, CSA, CSA international



Chromatotec® is specialized in VOC, Sulfur and permanent gases analysis at trace and ultra-trace levels (%, ppm, ppb, ppt). Please visit our website for more details.

Updated: February 2021

# WWW.CHROMATOTEC.COM

# TRS**MEDOR**®

**ppm** (M51) or **ppb** (M52)

# Online analysis and monitoring of odorous sulfur

# compounds

# Description:

The TRSMEDOR® is an autoGC-ED (MEDOR® Electrochemical wet cell Detector) for the analysis and monitoring of sulfur compounds in air: H<sub>a</sub>S, Mercaptans, Sulfides,

- Two versions exist according to levels of concentration expected:
- The TRSMEDOR® ppm
- The TRSMEDOR® ppb

#### **Principle:**

- · Automatic sampling using a loop linked to sampling pump
- · Automatic loop injection on metallic capillary column
- Isothermal gas chromatograph
- · Detection of all compounds eluting from the column performed by MEDOR® Detector: Electrochemical wet cell Detector which is SSD Sulfur Specific Detector.
- Signal provided by reaction between the wet cell electrolyte and the sulfur compounds

## Key points:

- · Automatic calibration/validation of the data, with embedded permeation tube
- · Continuous monitoring with automatic online sampling
- Analytical performances:
  - · Specific, linear and very sensitive to sulfur compounds
  - · Results validation by automatic standard injection
  - Long term stability using detector installed in reservoir
- Extremely low maintenance
  - · Very long life time detector with electrolyte, up to 10 years
  - · Low gas consumption, can be reduced in option
  - More than 10 years data storage
  - · No cylinders required thanks to internal calibration tube and gas generators
- · Automatic control with process device
- · Intelligent system with tunable and interactive alarm levels
- Powerful VISTACHROM Chromatotec<sup>®</sup> software:
- Remote monitoring & injection control
- · Full traceability with on board archiving of results and chromatograms
- . QC Set up and control of threshold alarms
- Data export by MODBUS / 4-20 mA / 0-10 V
- · Time stamp results

### **Options:**

- Multiple stream selector (up to 16 streams with one analyzer)
- · Modeling software with weather station for live odor/chemical impact
- Explosion proof version Exp or Exd for ATEX, IECEx zone 1 and 2 and also for CSA C1D2
- · Calculation modules (Average / Statistics / Odor unit OU e/m3 and more)
- Automatic data transfer through: Module for 4 outputs 4-20mA / Modbus RTU or TCP IP / MGS1
- Nitrogen or air generator
- 24 V DC power supply
- · Electric selection valve to reduce air consumption
- Wall mounted box XXX934



# **Technical Specifications:**

#### Reduced sulfur compounds analysis:

- · Speciation and Total Reduced Sulfur by sum (TRS): H2S, SO2, DMS, MM, DES, DMDS, EM compounds
- Detection limits\* for H2S, SO2, DMS, MM, EM:

#### TRSMEDOR<sup>®</sup> ppm LDL ≤ 0.1 ppm

#### TRSMEDOR<sup>®</sup> ppb $\leq$ 1 ppb

\*more sensitive analyzers available upon request with special application

#### Range (adjustable depending on application):

• 0/10 or 0/100 or 0/1000 (ppb or ppm)

## Calculation: Odor Index, Total Sulfur, Total mercaptans

- Relative Standard Deviation:
  - RSD < 3 % on concentration over 48H
  - RSD < 0.5% on retention time over 48H</li>

#### Cycle Time for the following different analyses:

· H2S, SO2, MM, EM, DMS, DMDS, DES 600s With special application following compounds can be added: IPM, TBM, NPM, 2BM, IBM, NBM, MES, THT and THT 1200s

#### Supervisor:

- · Embedded computer Windows® based with LCD display
  - 128 GB of Hardware storage on SSD memory

### Linearity:

• > 0.995 for all compounds

#### Communication:

· Ethernet, remote control

#### Gas supply:

- Carrier: Dry air or N2 (3 bars): ≤ 4 ml / min.
- CALIB: in continuous ~ 50 ml / min.
- CALIB during validation ~ 250ml/min for M52 configuration
- · Pneumatic valve 90ml/commutation

#### Power supply:

- Main: 230V 60Hz or 115V / 50Hz
- In case of power loss, the instrument will restart automatically

#### Electrical consumption:

• 150 VA

#### Dimensions and weights:

- Rack: 19" (5U) • Height: 222 mm
- · Height: 800 mm
- Net weight: 22 Kg
- Net weight: 40 Kg

Wall mounted box:

# To order:

Model: TRSMEDOR<sup>®</sup> ppb inbuilt computer 5U with CALIB M52022 TRSMEDOR<sup>®</sup> ppm inbuilt computer 5U with CALIB M51022

Chromatotec® is continuously improving its products, therefore these specifications are subject to change without notice

# To contact us: sales@chromatotec.com

**NORTH AMERICA** Houston - USA

EUROPE Bordeaux- FRANCE

ASIA Beijing - CHINA

#### Width: 482mm • Width: 600mm • Depth: 660 mm

- Depth: 300 mm